


NOTE To facilitate the removal of the R.F. Chassis or Changer Mechanism drawer follow the procedure as listed.


1. Remove the Cabinet Back.
 2. Withdraw Power, A.C. Switch and A.C. Phono Plugs from the sockets on the Power and Audio Chassis and the clamps on the cabinet.
 3. Remove all staples which have been used on the connecting leads to R.F. Chassis.
 4. Remove Ant. & Gnd. terminal strip.
 5. Remove the two triangular stops from the rear of the metal drawer slides, one each side, by squeezing together with a pair of pliers and pulling down.
- The drawer can now be removed by pulling it from front of cabinet.
To replace drawer stops press back into metal slides until the extrusions on the stops engage the slides.



Nominal sensitivity in Microvolts for 500 milliwatts output. Signal measured 30% at 450 cps. (60 FM equivalent to 80dB AXC.)

Applied to (see I.F. Tuning)	Thy. Stages	455 KC.	1000 KC.	10.7 MC.	100 MC.
6BA6	1, 2, 3	455 KC.	1000 KC.	10.7 MC.	100 MC.
6B6	1, 2, 3	455 KC.	1000 KC.	10.7 MC.	100 MC.
6BE6	1, 2, 3	455 KC.	1000 KC.	10.7 MC.	100 MC.
6AT6	1, 2, 3	455 KC.	1000 KC.	10.7 MC.	100 MC.
6AL5	1, 2, 3	455 KC.	1000 KC.	10.7 MC.	100 MC.

STRINGING DETAIL



Electrohome Balmoral 45FM, Chippendale FM, Kingsway 45FM & Westmount FM

