


Marconi Model 216 Alignment Procedure, Dial Cord & Layout



NOTE: -Ground lead from signal generator should be connected to chassis through a 0.1 Mfd. capacitor.

This connection to be made through a 0.1 Mfd. capacitor to lug on R.F section of gang.

^{##} Before proceeding with R.F. alignment, see that pointer is set over last division on left hand side of dial scale with gang at maximum.