

ALIGNMENT CHART

Opera- tion Steps	SIGNAL GENERATOR		RECEIVER		
	Connections to Receiver	Frequency	Tuning Capacitor	See Notes	Adjust in Stated Order for Maximum Output
1	To pin 1 of 12BA6 through 0.05 mf capacitor	455 kc.	Minimum		2nd I.F. Transf. L7-L6
2	To pin 7 of 12BE6 through 0.05 mf capacitor	455 kc.	Minimum	A	1st I.F. Transf. L5-L4
3	To Blue Lead on Antenna Rod through 5 mmf capacitor*	1500 kc.	1500 kc.	B C	Oscillator Trimmer C6
4	To Blue Lead on Antenna Rod through 5 mmf capacitor*	1500 kc.	1500 kc.	С	Antenna Trimmer C3

NOTE A - After completing operation No. 2 do not readjust L7 - L6.

NOTE B — Replace the chassis in the cabinet to obtain the 1500 Kc. setting of the gang condenser.

NOTE C — Upon completion of operation 4, disconnect generator leads from receiver. A radiated signal of 1500 Kc. from generator may be used instead of the connection to antenna.



