



**CAUTION:**  
 THERE IS POSSIBILITY WITH SOME EQUIPMENTS IN SOME LOCATIONS THAT THE LEFT HAND AND RIGHT HAND CHANNELS WILL BE INTERCHANGED. SHOULD THIS OCCUR, THE WIRES CONNECTED TO PINS N° 4 & N° 6 ON THE OCTAL PLUG PL-2 SHOULD BE INTERCHANGED AT THE PLUG TERMINALS.

R17, R18, R19 & R20 = 2.2 K

# FLEETWOOD 2065

2065 and variants used in many Fleetwood and Silvertone (Sears Canada) models

# F.M. Stereo Multiplex Alignment

## FLEETWOOD 2065

2065 and variants used in many Fleetwood and  
Silvertone (Sears Canada) models

### Alignment Instructions

1. Inject .1 volt of 19 KC. into input at TP-3.
2. Connect scope to either side of secondary of 38 KC. transformer (L4) to ground and peak top and bottom cores of both the 19 KC (L2) and the 38 KC. transformer (L4) for maximum.
3. Turn the top core of the 19KC. (L2) transformer one-quarter turn anti-clockwise.
4. Inject 1 to 5 volts of 67.5 KC. into input at TP-3 and adjust SCA trap (L3) for minimum deflection. This completes the alignment procedure.

