



Figure 2—Schematic Circuit Diagram

NUMERALS SHOWN ALONG WITH TUBES SHOW NUMBER OF TUBES REQUIRED IN SENTRY BOX UNIT

(* Resistor R-31 may be 56 ohms on some models. Replace with Stock No. 12980)
 (** 120-ohm resistor not required when replacing resistor R-31 with Stock No. 12980)