



INPUT SELECTOR SW (M5) SHOWN IN "AUX" POSITION SW SEQUENCE:
1 - AUX
2 - TUNER
3 - TAPE
4 - PHONO

