

MODEL 1000 PARTS LIST

Item	Description
R ₁	100 Ohm Trimmer Pot.
R ₂	220 Ohm Resistor ½ Watt 1%
R ₃	560 Ohm Resistor ½ Watt 1%
R ₄	5K Ohm Trimmer Pot.
R-5	10K Ohm Resistor ½ Watt 10%
R-6	47K Ohm Resistor ½ Watt 10%
R-7	820K Ohm Resistor ½ Watt 10%
R-8	4.7M Ohm Resistor ½ Watt 10%
R-9	6.8M Ohm Resistor ½ Watt 10%
R-10	22M Ohm Resistor ½ Watt 10%
R-11	100 Ohm Resistor 1 Watt 10%
R-12	100 Ohm Resistor 1 Watt 10%
R-13	1K Ohm Resistor 1 Watt 10%
R-14	3.9K Ohm Resistor 1 Watt 10%
R-15	4.7K Ohm Resistor 1 Watt 10%
R-16	15K Ohm Resistor 1 Watt 10%
R-17	10K Ohm Resistor 2 Watt 10%
R-18	18 Ohm Resistor 3 Watt 10%
R-19	18 Ohm Resistor 3 Watt 10%
R-20	270 Ohm Resistor 5 Watt 10%
R-21	270 Ohm Resistor 5 Watt 10%
R-22	1K Ohm W.W. Load Pot.

Item	Description
R-23	100 Ohm Trimmer Pot.
R-24	1K Ohm Trimmer Pot.
R-25	40 Ohm Trimmer Pot.
V ₁	6AT6
M ₁	0-1MA Meter
D ₁	1Y4 Rectifier
D ₂	Bridge Rectifier
D ₃	Bridge Rectifier
C ₁	200-200 mfd 10V
C ₂	100 mfd 25V
C ₃	100 mfd 25V
C ₄	.01 mfd. 600V
C ₅	.01 mfd 600V
C ₆	.01 mfd 600V
C ₇	.05 mfd 600V
B ₁	NE-2 Neon Lamp
B ₂	#44 Lamp
B ₃	#44 Lamp
T ₁	Power Transformer
S ₁	5 pol 4 pos Function Switch
S ₂	1 pol 12 pos Selector Switch
S ₃	13 Sect. Lever Switch