



## Models 14 (new run), 26, 27, 206

MODEL 14 (New Run): New run of Model 14 is identical with Model 14 as described in Service Bulletin No. 320, except for dial and cabinet design. New parts for the new run of Model 14 are listed below:

<u>Name</u>	<u>Part No.</u>
Cabinet	10462A
Dial Scale	27-5559
Dial Pointer	27-4891
Knob	27-4815-01
Tuning Condenser	31-2431

Sets with these changes are identified as Run 2.

MODEL 26: Model 26 is identical with Model 10 as described in Service Bulletin No. 320, except for cabinet and dial design. New parts for Model 26 are listed below:

<u>Name</u>	<u>Part No.</u>
Cabinet	10374A
Dial Scale	27-5565
Dial Pointer	27-4891
Knob	27-4815-01
Tuning Condenser	31-2427

MODEL 27: Model 27 is identical with Model 12 as described in Service Bulletin No. 320, except for cabinet and dial design. New parts for Model 27 are listed below:

<u>Name</u>	<u>Part No.</u>
Cabinet	10451B
Cabinet Back	27-9564
Knob	27-4899
Tuning Condenser	31-2436

MODEL 206: Model 206 is identical with Model 201 as described in Service Bulletin No. 322, except for cabinet and dial design. New parts for Model 206 are listed below:

<u>Name</u>	<u>Part No.</u>
Cabinet	10462A
Dial Scale	27-5565
Dial Pointer	27-4891
Knob	27-4815-01
Tuning Condenser	31-2427

Tuning Condenser changes shown above do not involve any electrical change, but are mechanical changes only to allow different type mounting, and to accommodate new dial pointer.