


# MODELS R93C & R93E Victrola Attachments



## REPLACEMENT PARTS FOR MODELS R93C & R93E

Insist on genuine factory tested parts, which are readily identified and may be purchased from authorized dealers.

STOCK NO.	DESCRIPTION	STOCK NO.	DESCRIPTION
<b>RECEIVER ASSEMBLIES</b>		9842	Pickup-Pickup crystal and arm complete.....
S-2277	Base-Motor support, damper and bearing cup assembly.....	12539	Screw-Pickup needle screw
31046	Bearing-Motor bearing Assembly.....		
31041	Cap-Rubber spindle cap		
31047	Cushion-Rubber cushion for bearing.		
S-2264	Motor-Phonograph motor complete with turntable less mounting screw assembly 60 cycle.....		
S-2265	Motor-Phonograph motor complete with turntable less mounting screw assembly 25 cycle.....		<b>MISCELLANEOUS ASSEMBLIES</b>
31040	Mounting-Turntable top rubber mountings for 60 cycle turntable.	31055	Case-Bakelite case and bottom cover (R93E only).....
S-2271	Retainer-Turntable retaining ring, washer and bushing assembly.....	31051	Foot-Rubber foot for cabinet (R93E only).....
32076	Turntable-Finished turntable top plate only 25 cycle.....	3961	Knob-Volume Control knob.....
31039	Turntable-Finished turntable top plate only 60 cycle.....	32500	Mounting-Pickup arm mounting nut, washer and rubber spacer.....
4083	Washer-Leather spacing washer	S-2289	Mounting-Motor mounting screw assembly (R93E).....
14231	Washer-Metal spacing washer	S-2290	Mounting-Motor mounting screw assembly R93C 25 cycles.....
	<b>PICKUP AND ARM ASSEMBLIES</b>	S-2291	Mounting-Motor mounting screw assembly R93C 60 cycles.....
31744	Base-Pickup arm pivot shaft and base assembly.....	31048	Plug-Phonograph cable plug.....
31050	Crystal-Pickup crystal cartridge and needle screw.....	9428	Switch-Radio Record switch and cable assembly.....
		31052	Volume control and on-off switch (R1, S1).....