


**Models
A-40 - A44
1929-30**



MODEL 'A 44' 1929-30 SIMILAR BUT HAS EXTRA R.F. STAGE AND USES (2) 250.

R.F. Mod 40 130V 6.6ma Det 20V 1.2ma
" 44 102V 4ma " " 8ma

Mod 40 18ma 120V 6-4ma
44 100V 5-6ma
44 102V 5-6ma

**SONORA
MODEL 'A 40
1929-30**

NOTE: A-44 USES (2) 2816

For Models C34-C35 see S-Warner Data Sheet .7.