



SPEAKER

## TOP VIEW OF CHASSIS

## Alignment

- Signal Generator at 455 Kcs. connected to Ant. and Gnd. post on rear
- of loop Antenna. Dial at 1500 Kcs, B/C Band. Adjust I.F. trimmers ClOP, ClOS, C9P, C9S, for maximum gain. Adjust I.F. trimmers ClOP, CloS, C9P, C9S, for maximum gain. Signal generator at 1500 Kcs, dial at 1500, adjust oscillator trimmer C4 to maximum signal, and antenna trimmer C3 for maximum output. Turn dial and Sig. Gen. to 600 Kc. and adjust C5 for maximum output,
- return to 1500 Kc and adjust C3 and C4 again for maximum.
- Above adjustments to be made with baseplate on chassis.