



No.	Dummy Antenna	Connection of Signal Generator to Receiver	Signal Generator Frequency	Receiver Dial Setting	Trimmers to be Adjusted	Description of Adjustment
1	.1 mfd cond.	Stator connection of antenna section (front) of gang	455 kc	Anywhere that does not affect the signal	2nd I.F. 1st I.F.	Peak both transformers for maximum output, then repeat until no further increase in output is obtained
2	.1 mfd cond.	Stator connection of antenna section (front) of gang	1750 kc	Gang at minimum	Oscillator trimmer on rear section of gang	Adjust to bring in signal
3	Standard Dummy	Antenna Wire	1500 kc	Tune to 1500 kc signal	Ant. trimmer on front section of gang	Adjust for maximum output

1946-47 MODEL R486S