



1946-47

**MODEL R 535**

No.	Dummy Antenna	Connection of Signal Generator to Receiver	Signal Generator Frequency	Receiver Dial Setting	Trimmers to be Adjusted	Description of Adjustment
1.	.1 mfd cond.	Stator connection of antenna section (rear) of gang	455 kc	Anywhere that does not affect the signal	2nd I. F. I. F.	Peak both transformers for maximum output, then repeat until no further increase in output is obtained.
2.	.1 mfd cond.	Stator connection of antenna section (rear) of gang	1500 kc	1500 kc	Osc. trimmer on front section of gang	Adjust to bring in signal
3.	Standard Dummy or 200 mfd. Cond.	Antenna	1500 kc	1500 kc	Trimmer on Osc. Section of gang	Adjust for maximum output