


302175 PUSH BUTTON SWITCH WITH ALL BUTTONS SHOWN IN OUT POSITION



MODEL R-456 1939-40

ALIGNMENT INSTRUCTIONS SAME AS MODEL R-455 (DATA SHEET 80)

1.F. 456K.C.

60 Cy Console R-45665  
25 Cy Console R-45666

NOTE: ALL voltages measured from tube socket to chassis with a 1000 Ohm per volt meter.