

VIKING

Portable Electric Phonograph

MODEL PAP-435

4 Speed 2 Tube Manual

Undistorted Power Output85 Watts
 Maximum Power Output 1.5 Watts
 Power Consumption 33 VA.
 Tubes..... 50C5 35W4

For Operation on 105 - 125 Volts A.C. Cycle as Marked.

REPLACEMENT PARTS LIST

FINAL ASSEMBLY

12-17650-53	Port Phono Case - Green & White
12-17650-54	Port Phono Case - Rust & White
13-77-01	Curtain
13-78-01	Motorbird - BSR UA8
16-90010-02	BSR UA8 Record Changer 60 cycle
16-100010-01	BSR UA8 Record Changer 25 cycle
16-220002-01	Motor & Mounting Plate Assembly
16-250004-02	BSR TC8H Cartridge
16-120017-01	LP Stylus - BSR TC8R
16-120017-02	78 RPM Stylus - BSR TC8G
19-50003-01	5" P.M. Speaker
53-40-08	Knob - Loudness
53-40-09	Knob - Off-On-Tone
53-141-01	Viking - Nameplate

CHASSIS ASSEMBLY

24-80013-08	Output Trans. 3.2 ohm
41-19-01	Control - Volume
41-20-01	Control - Tone-Off-On
42-14-02	WW Resistor 265 ohm 10% 7W
44-56-01	Electrolytic 80,30x150V, 40x25V

CAUTION FOR SERVICEMEN

Any serviceman working with this unit when it is out of the cabinet should take special care not to come in contact with any ground connections.

When writing for Service Information, please quote model number and serial number. Always order service parts by part number. Part numbers are positive identification which ensures fast service and avoids unnecessary delays.

