

Television and Radio Service Bulletin

GENERAL MERCHANDISE OFFICE

Insert NOW in
Radio Service Manual
as: Data Sheet No.

KITCHENER

October 21, 1959


RCS 406 - RCS 407

In some cases, the brass discs used on the control shafts on the above models have slipped out of place during normal use. This condition may be corrected by removing the dial glass and cementing the disc to the shaft. Any all purpose household cement may be used for this purpose.

On later production the shafts have been scored to prevent this problem.

Yours very truly,

Dominion ELECTROHOME Industries Limited



D. Kehn
Supervisor, Field Service

DK/js