



Northern Electric 5702

**For least trouble use 1:1 transformer on Instruments or Set.
Where the electrical noise level interferes with alignment a screen booth must be used.**

Alignment Frequency	Dummy Antenna	Receiver Connection	Items to be adjusted for maximum output and their location
IF 455 KC	.1 uf	Rear Gang Section	With gang open adjust slugs in I.F. T4 then I.F. T3.
RF 600 KC	1000 ohm	Antenna lead	Adjust tuning slug in oscillator coil T2
RF1400 KC	1000 ohm	Antenna lead	Adjust trimmer C3 on front gang section
RF 600 KC	1000 ohm	Antenna lead	Readjust tuning slug in oscillator coil T2
RF1400 KC	1000 ohm	Antenna lead	Readjust C3 on front gang section
			Adjust C2 on rear gang section