



WINDING POLARITY
"S" DESIGNATES START OF WINDING
"F" DESIGNATES FINISH OF WINDING

"B" BATTERY PLUGS
TOP VIEW

Alignment Phonola Data Sheet 89;
"ELECTROHOME 8XXX & Z8XXX RADIO ALIGNMENT DATA"

Phonola - Electrohome 7B51-S, 7B51-S-1 & 7B51-M-1

RCC - Phonola Data Sheet 74 (Upper) - 1938-39