

### Stromberg-Carlson Model 154 A.M. Tuner



### Stromberg-Carlson Model 154 F.M. Tuner



### Stromberg-Carlson Model 154 Voltage Adjustments, **Pushbutton Adjustments & Chassis Layouts**

### NORMAL VOLTAGE READINGS

Take all readings with chassis operating and tuned manually to  $1000\ \mathrm{kc.}$  or  $47\ \mathrm{megacycles}$ —no signal. Use a line voltage of 120 volts or make allowance for the variation.

Use a good high resistance voltmeter having a resistance of at least 1000 ohms per volt.

Take all D. C. readings on the 500 volt scale, except when an asterisk appears.

Read from indicated terminals to chassis base.

for position of terminals. A. C. voltages are indicated by italics.

AMPLITUDE MODULATION AND POWER AMPLIFIER CHASSIS, 154 RECEIVER

		TERMINALS OF SOCKETS						
Tube Circuit	1	2	3	4	5	6	7	8
R. F. Amplifier	0	0	0	0	0	+100	6.3.	0
Modulator and Oscillator	0	0	+260	+100	-20*	0	6.3	0
I. F. Amplifier	0	0	0	0	0	+100	6.3	0
Demod., A. V. C., Audio Amp.	0	0	+3	0	0	+54	6.3	0
Audio Inverter	0	+165	0	0	+165	+2	0	6.3
Output	0	0	+260	+263	0		6.3	+14
Output	0	0	+260	+263	0	_	6.3	+14
Rectifier		+370	_	355		355	annon .	+370
Speaker Socket	+360	0	0	+370	+370	-	+265	_
Power Socket	+263	0	0	50	50	6.3	0	+200
	R. F. Amplifier  Modulator and Oscillator  I. F. Amplifier  Demod., A. V. C., Audio Amp.  Audio Inverter  Output  Output  Rectifier  Speaker Socket	R. F. Amplifier	Circuit         1         2           R. F. Amplifier         0         0           Modulator and Oscillator         0         0           I. F. Amplifier         0         0           Demod., A. V. C., Audio Amp.         0         0           Audio Inverter         0         +165           Output         0         0           Output         0         0           Rectifier         -         +370           Speaker Socket         +360         0	Circuit         1         2         3           R. F. Amplifier         0         0         0           Modulator and Oscillator         0         0         +260           I. F. Amplifier         0         0         0         +3           Demod, A. V. C., Audio Amp.         0         0         +3           Audio Inverter         0         +165         0           Output         0         0         +260           Output         0         0         +260           Rectifier         -         +370         -           Speaker Socket         +360         0         0	Circuit         1         2         3         4           R. F. Amplifier         0         0         0         0           Modulator and Oscillator         0         0         +260         +100           I. F. Amplifier         0         0         0         0           Demod, A. V. C., Audio Amp.         0         43         0           Audio Inverter         0         +165         0         0           Output         0         0         +260         +263           Output         0         0         +260         +263           Rectifier         -         +370         -         355           Speaker Socket         +360         0         0         +370	Circuit         1         2         3         4         5           R. F. Amplifier         0         0         0         0         0         0           Modulator and Oscillator         0         0         +260         +100         -20*           I. F. Amplifier         0         0         0         0         0         0           Demod, A. V. C., Audio Amp.         0         43         0         0           Audio Inverter         0         +165         0         0         +165           Output         0         0         +260         +263         0           Output         0         0         +260         +263         0           Rectifier         -         +370         -         -555         -           Speaker Socket         +360         0         0         +370         +370         +370	Circuit         1         2         3         4         5         6           R. F. Amplifier         0         0         0         0         0         +100         -20*         0           Modulator and Oscillator         0         0         +260         +100         -20*         0         0         +100         +100           I. F. Amplifier         0         0         0         0         0         +100         +100           Demod, A. V. C., Audio Amp.         0         0         +3         0         0         +54         +2           Audio Inverter         0         +165         0         0         +165         +2           Output         0         0         +260         +263         0         -           Output         0         0         +260         +263         0         -           Rectifier         -         +370         -         355         -         355           Speaker Socket         +360         0         0         +370         +370         +370         -	Circuit         1         2         3         4         5         6         7           R. F. Amplifier         0         0         0         0         0         +100         -20*         0         6.3           Modulator and Oscillator         0         0         +260         +100         -20*         0         6.3           I. F. Amplifier         0         0         0         0         +100         6.3           Demod, A. V. C., Audio Amp.         0         0         +3         0         0         +56         6.3           Audio Inverter         0         +165         0         0         +165         +2         0           Output         0         0         +260         +263         0         -         6.3           Output         0         0         +260         +263         0         -         6.3           Output         0         0         +260         +263         0         -         6.3           Rectifier         -         +370         -         355         -         355         -         555         -         2         +263           Speaker Socket

### INSTRUCTIONS FOR SETTING UP PUSH BUTTONS

IMPORTANT: The stations selected should be the local or favorite stations which give good reception at all times. If a Frequency Modulation station is available, it may be set up on one of the push buttons on the No. 154 Receivers.

Set up stations in the daytime to avoid unnecessary interference. Allow the set to run for about twenty minutes before setting up stations.

Always use the tuning indicator unit when setting up stations, in order to determine when the station is exactly in tune.

- 1. Turn the receiver "On".
- On the No. 154 Receivers, be sure the "Phono" and "F. M" buttons are in the proper position to receive the desired stations.
- 3. Set the range switch to the "BC" position.
- 4. Turn volume control about three-quarters of the way on (in a clockwise direction).
- 5. Pull the six station push buttons off their levers.
- 6. Remove the call letters of the six selected sta-tions from the call letter sheets, which are in an envelope stapled to the cabinet. Insert the station call letters part way in the slots at the

sides of the buttons. Next, insert a transparent tab in each slot in front of the station letters. Then push both the transparent tabs and the call letters all the way into the slot. (A pencil eraser may be helpful.)


- 7. Loosen the set screw of the lever to be set up.
- Push in the lever and manually tune in the desired station, observing the tuning indicator in order to obtain exact resonance.


IMPORTANT: For accurate set-up, be sure that the lever is pushed in, in the same manner and with the same amount of pressure as will be used when operating the push buttons.

9. Tighten the set screw. Be sure not to disturb the adjustment in any way while tightening the

- 10. Place the proper button on the lever.
- Check the accuracy of the adjustment by detun-ing the station and retuning with the button several times, pushing the button with an even pressure. Readjust if necessary.
- 12. Set up the other five stations in the same

### Stromberg-Carlson Model 154 Chassis Layout





# Stromberg-Carlson Model 154 AM / FM Receiver Alignment Data

# NEVER REALIGN UNLESS ABSOLUTELY NECES-

GENERAL. All aligning adjustments are carefully made at the factory with special equipment which is designed for aligning Frequency Modulation receivers. The limitations of commercial oscillographs and other ordinary test equipment are such that alignment should not be attempted in the field unless absolutely necessary.

If alignment is attempted, it will not be successful unless the instructions which follow are adhered to exactly.

# The following equipment will be required:

- 1. Standard signal generator with sweep circuit
- Wide band sweep signal generator.
- Microammeter-0 to 200 microamps
- Center "0" microammeter with 100 divisions either side of "0".

See location chart for location of all aligners

# ALIGNING PROCEDURE (AMP. MOD.)

# Dial Pointer Adjustment. (A. M.)

With the plates of the gang tuning capacitor fully engaged, check to be sure that the dial pointer is in a vertical position directly on the calibration marks located at the low frequency end of the dial scale. Adjust if necessary.

## Ħ. Intermediate Frequency Adjustments. (A. M.)

- Set the range switch to standard broadcast
- Tune set to extreme low frequency end of dial
- ço erator to the ground terminal of the chassis Connect the ground terminal of the signal gen-
- Introduce a modulated signal of 455 kilocycles to the grid of the 85A7 Modulator and Oscillator tube (terminal No. 8), using a 0.1 mmf. capacitor in series with the output lead of the signal generator.
- 5 Adjust the I. F. aligners for maximum output in the following order:
- a. Secondary of second I. F. transformer
- b. Primary of second I. F. transformer.
- Primary of first I. F. transformer. Secondary of first I. F. transformer

## Ξ Radio Frequency Adjustments. (A. M.)

# Standard Broadcast Range (A Band)

## Replace the 0.1 mf. capacitor in series with the output lead of the signal generator with a 200 mmf. capacitor and connect it to the antenna terminal of the chassis.

- Set the signal generator frequency and the receiver tuning dial to 600 kc.
- Set the range switch to the Standard Broadcast range (A Band).
- Adjust the 600 kc. oscillator and R. F. aligners (iron cores) for maximum signal

- Repeat operations three and four
- Repeat operations five and six.
- 9. Connect the center "0" microammeter and the 5 megohn resistor in series with it across the whole discriminator load. (From ground to the junction of R-23. I megohm resistor and C-29.04 mf. capacitor.)
- 10.
- 11. Vary the frequency of the standard signal generator, making sure that the voltage peaks, which should be of the same magnitude, are the same number of kilocycles off on either side of resonance. Any departure from these conditions may be corrected by a slight re-adjustment of the primary.

### IV. Radio Frequency Adjustments. (F. M.)

- :-Set the signal generator frequency a receiver tuning dial to 48.5 megacycles and the
- 2 Replace the 0.1 microfarad capacitor in series with the output lead from the signal generator with a 100 ohm resistor and connect it to one of the F. M. terminals on the back of the chassis.
- ω. Connect the ground ator to the other F. lead of the signal gener.
  M. terminal.
- Adjust the oscillator aligner (air trimmer)
- Adjust the R. F. and antenna aligners for maximum signal on the 0 to 200 microammeter, maintaining the center "0" microammeter at "0" at all times by rotating the receiver dial slightly back and forth.

## Medium Wave Range (B Band)

# Replace the 0.1 mf. capacitor in series with the output lead from the signal generator with a 400 ohm carbon type resistor and connect it to the antenna terminal of the chassis.

- 2
- ω.
- Set the signal generator frequency and the receiver tuning dial to  $1500~\mathrm{kc}.$
- Adjust the 1500 kc. oscillator, R. F. and antenna aligning capacitors for maximum signal
- Adjust the secondary of the discriminator transformer for center "0" reading of the microammeter.
- e: Connect the wide band sweep signal generator to the grid of the 6SA7 Modulator and Oscillator tube socket and make slight readjustments of the I. F. transformers for proper curve, since there is some interaction between these stages and the discriminator.

# ALIGNING PROCEDURE (FREQ. MOD.)

# Dial Pointer Adjustment.

Before alignment is attempted, be sure that the variable capacitor plates of the F. M. tuner are fully meshed with the variable capacitor plates of the A. M. tuner when turned all the way in.

## II. Intermediate Frequency Adjustments (F. M.)

Note: All I. F. adjustments are made using a wide band sweep signal generator with a sweep circuit of plus or minus 300 kilocycles.

- Push in the F. M. button.
- 2 Tune the set to the extreme high frequency end of the dial (50 megacycles).
- ω. Connect the 0-200 microammeter across the R-17 4700-ohm resistor. (This resistor is mounted on the terminal strip located on the side of the base.
- Connect the oscillograph between ground and the junction of C-43 .01-mf. capacitor and R-26 100,000-ohm resistor located on the same ter-minal strip with the R-17 resistor.
- 5. Connect the ground terminal of the wide band sweep signal generator to the ground terminal of the 6AC7 second I. F. tube socket.

Set the range switch to the Medium Wave range (B Band).

Introduce a signal of 4.3 megacycles to the grid of the 6ACT second I. F. tube socket (terminal No. 4), using a 0.1 capacitor in series with the output lead of the signal generator. Keep the 0 to 200 microammeter at approximately 100

- Set the signal generator frequency receiver tuning dial to 3.5 megacycles. frequency and
- Adjust the oscillator R. F. and antenna aligning capacitors for maximum signal.

## Short Wave Range (C Band)

- Leave the signal generator connected in the same manner as when adjusting the Medium Wave Range (B Band).
- 2 Set the range switch to the Short Wave Range (C Band).
- Set the signal generator frequency receiver tuning dial to 6 megacycles. and the

10.

Adjust the second I. F. transformer in the same

Connect the ground lead of the signal generator to the ground terminal of the 6AB7 first I. F. tube socket.

Connect the output lead of the wide band sweep signal generator and the 0.1 microfarad capacitor in seres with it to the grid of the 6AB7 first I. F. tube socket (terminal No. 4).

Adjust the secondary and primary of the third I. F. transformer for maximum reading on the

microamps.

0 to 200 microammeter.

ω

Adjust the 6 megacycle oscillator, antenna aligners (iron cores) for , R. F. and r maximum

Connect the output lead of the wide band sweep signal generator with the 0.1 microfarad capa-citor in series with it to the grid of the 8SA/7 Modulator and Oscillator tube (terminal No. 8).

Set the Set the signal generator frequency receiver tuning dial to 17 megacycles and

5.

6. Adjust the 17 megacycle oscillator, R. F. antenna aligning capacitors for maxic

13.

Adjust the first I. F. transformer in the same

12.

Connect the ground terminal of the signal generator to the ground terminal of the 6SA7 tube

- Repeat operations three and four
- Repeat operations five and six.
- Note: After the receiver has been placed in the cabinet, plug the loop into the socket and readjust the Standard Broadcast, Medium Wave and Short Wave anteena high frequency shunt aligners for maximum signal.

## H. Discriminator Adjustment (F. M.)

- Connect the ground terminal of the standard unmodulated signal generator to the ground terminal of the 6AB7 first I. F. tube socket.
- Connect the output lead of the unmodulated standard signal generator to the grid of the 6AB7 first I. F. tube (terminal No 4), using a 0.1 microfarad capacitor in series with the out-put lead of the standard signal generator, leav-ing the wide band sweep signal generator con-nected to the grid of the 6SA7 Modulator and Oscillator tube socket.
- <u>ي</u> Adjust the attenuator of the wide band sweep signal generator for a curve on the oscillo-
- 4. Set the frequency of the unmodulated standard signal generator to approximately 4.3 megacycles and adjust the attenuator for interference patterns on the oscillograph. Adjust the unmodulated standard signal generator frequency until interference patterns on each trace come together. (This is done in order to assure that the frequency of the standard signal generator which is used to align the discriminator coincides with the mean frequency of the wide band sweep signal generator)
- Remove the wide band sweep signal generator
- Connect the center "0" microammeter with a 5 megohm resistor in series across one-half of the discriminator load. (From ground to the junction of the two .1 megohm resistors R-23
- Set the attenuator of the standard signal generator for maximum output.
- 00 Adjust the primary of the discriminator transformer for maximum reading on the center "0" microammeter.