

MODIFICATION FOR HUM - S/400, S/600

1. Remove ground connection from volume control to chassis and reground control through the shield of your shielded wire direct to tube socket of 12AX7.

2. Balance Control.

Remove C53 and C54 and connect R41 and R42 direct to balance control. Remove R45 and R46 and ground control directly to ground. Connect C53 and C54 from centre tap of balance control to grid (7) of 12AX7 and add 2 Megohm resistor from grid to ground.

On S/600, remove A.C. filament supply from 1st 12AX7, wire filament in series for 12V, and connect filament to D.C. supply point R62 and rectifier PA 305. Change rectifier PA 305 (300 mA) to 500 mA rectifier.

*Please Note;*

This is exactly how we received this information from Clairtone with no reference number, author or date?