


**TUBE LOCATIONS**



The amplifier uses one 12AX7, one 6AV6, one 6SN7GT and two 6W6GT tubes. To insure balanced output from the push-pull output stage, it is suggested that the 6W6GT tubes be replaced in pairs.

AMPLIFICATION CHECK	"COMP" CONTROL SETTING	VOLUME CONTROL SETTING	TONE CONTROL SETTINGS	INPUT		OUTPUT	
				Frequency	Volts	Volts	Watts
FREQUENCY RESPONSE CHECK	"LON" Position	Fully Clockwise	Mid Rotation	1000 Cycles	0.25 Volts	4.5 Volts	6.5 Watts
	"LON" Position	Fully Clockwise	Mid Rotation	In steps between 20 and 30,000 Cycles	0.1 Volts	Volts	Db
							±2 Db