





## ALIGNMENT

### Rogers 14-52, Majestic 952, De Forest "Astor" (Chassis 9R513, 9M513, 9D513)

**I.F.** — Short out oscillator section of gang condenser. Connect generator through a .1 mfd. condenser to control grid of 6A7M tube (grid cap in position. With generator at 456 kc./s adjust I. F. trimmers C9, C8, C7 and C6 in that order for maximum output.

**R.F.** — Remove shorting link from gang condenser. Apply 1600 kc. signal through a .0002 mfd. condenser to antenna (Green) lead or terminal "A". Adjust C4 (oscillator) and C3 (R. F.) for maximum reading. Reset generator to 600 kc. and adjust C5 for maximum reading. Rock gang during this operation.

