

ALIGNMENT AND SENSITIVITY

STEP	APPLY SIGNAL AT KC.	TO	THRU SERIES DUMMY	SET GANG AT	ADJUST FOR MAX. OUTPUT	NOMINAL SENSITIVITY 50 MILLI-WATTS OUTPUT AT 400 C/S
1	455	12BA6 *1 PIN	.05	MINIMUM CAPACITY	2ND. I.F	1600 μ V
2	455	12BE6 *7 PIN	.05	MINIMUM CAPACITY	1ST. I.F 2ND. I.F	55 μ V
3	1640	ANT.	*	MINIMUM CAPACITY	OSC. TRIM.	—
4	1460	ANT.	*	RESONANCE	ANT. TRIM.	120 μ V/M
5	600	ANT.	*	RESONANCE	CHECK ONLY	400 μ V/M
6	530	ANT.	*	MAXIMUM CAPACITY	CHECK ONLY	—

* FASHION LOOP OF SEVERAL TURNS OF WIRE AND RADIATE SIGNAL INTO LOOP OF RECEIVER. ADJUST FOR MAXIMUM OUTPUT.



VIKING 54-19